



INSTALLATION INSTRUCTIONS

GH0806











The concrete slab should be at least 3" to 4" (8-10cm) thick. It must be level and flat to provide good support.



RECOMMENDED SLAB SIZE: 2690mm × 1850mm

BEFORE YOU START

Items Required:

Safety Gear				
	gloves	Safety Glasses	Shoes	Riveting Gun
Tools				
	Power drill	Screw driver	Pencil	Tape Measure

- Clear a working area to allow access on 4 sides. A raised work surface will make assembly easier.
- All parts are identified so when working through the instructions page by page the diagrams show where each part is positioned.
- Many of the holes have been pre-punched, to allow fixing using self-tapping screws or rivets, where additional holes are required a drill bit is included.
- Before starting, to avoid any accidental injury, we recommend the use of gloves to protect your hands, safety glasses to protect your eyes and shoes or boots to protect your feet.
- Please keep children away from your construction site.
- Most assembly can be completed by one person, assistance may be needed when you reach the erection stage.
- Please note: Some local government authorities have rules & regulations on shed installation and you may need approval to erect this shed.

STEPS:

1. Unpack all components from the carton and lay outside your work area and check parts against the part list on the next page.

2. Tip: Parts are identified with letters T=Top, U=Up, M-Middle, B= Bottom use these as a guide for where the parts go.























3. Refer to page "HOW PANELS ARE JOINED", the unique clipping method reduces the number of screws and rivets required and speed up assembly.

4. Work through assembly instructions Page by Page

































5. When completed place shed in position and anchor securely to the ground.

6. Clean up all metal pieces, rivets and screws.


PART LIST

picture	Part No.	QTY	Check	picture	Part No.	QTY	Check
	TPC2	4			PA2	7	
	DPA1	1			PA7	7	
	PA8	1			GLC	2	
	UF3A	2			GRC	2	
	BF3A	2			UF4A	2	
	BFB3	2			BF4A	2	
	UFB3	2			TF2	2	
	MF3B	2			MFB2	2	
	MF1A	1			MF2A	1	
	DFA3	1			DF1	2	
	DFA2	1			MS1	1	

PART LIST

picture	Part No.	QTY	Check	picture	Part No.	QTY	Check
	B2A	2			TR3	2	
	TL3	4			BFT1	1	
	MTA1	2			T1	1	
	MFA1	1			DFU1	1	
	DFU6	2			LG3	2	
	C1	8			C23	4	
	C7	8			S11	8	
	H1	1			H2	1	
	H3	1			J1	13	
	L1A	12			S3		
	S5				S8	20	
	S16	30			MSA	4	
	L1	2			L3	78	
	UF1	4			SH1	4	
	UV3	1			C12	8	
	F08	14			J1	7	

ANALYSIS DIAGRAM







BEFORE YOU START — HOW PANELS ARE JOINED








PUSH

Position U channel over one end of the joined sheets, working from one end push channel down to clip onto sheets, continue to the end of the channel pushing as you go.


A raised platform will make assembly easier




If you need to remove U channels from the panels, pull the channel along the panel from opposing ends. You may need someone to help with this.



J1





J1




J1







Join corners using part C1




BACK WALL ASSEMBLY




STEP 1.



	PA2	3		UF3A	1
	BF3A	1		UF4A	1
	BF4A	1		J1	2






STEP 2.




WALL ASSEMBLY

LEFT AND RIGHT WALL ASSEMBLY


	PA2	2		UFB3	1
	BFB3	1			


X 2








X 2


FRONT WALL ASSEMBLY











DOOR ASSEMBLY

	DPA1	1		DF1	2
	DFA2	1		DFA3	1
	C12	4			










DOOR ASSEMBLY

	DFU1	1		DFU6	2
	S3	6		L1A	6




DOOR ASSEMBLY










	SH1	2		S3	18
	S16	6		L3	18
	MSA	2		S5	18




PANEL CONSTRUCTION





MONTAGGIO CASSETTA

	MF2A	2		MF1A	1		C23	4		S3	44		J1	1
	MF3B	2		MF2A	1		L3	28		L1	2			

Use the holes of U channel drill new holes on the wall panel and fasten by using S3. Cap all S3 tips with L3.







BEAM CONSTRUCTION




Beam Assembly Process:

1. Fix main beam
2. Put secondary beam on the roof, do not fix at this stage
3. Fix one left and one right roof panel on the roof, so the position of secondary beam can be confirmed by overlapping the holes on roof panel and secondary beam, then fix secondary beam.






	UF1	4		S8	14
	B2A	2			




CENTRE ROOF BEAM






MONTAGGIO CASETTA

	TPC2	4		L3	20		S3	36
	UV3	1		S5	36			








TPC2




UV3

TR3










	TR3	2		S3	2		L3	2		S5	2
---	-----	---	---	----	---	--	----	---	---	----	---



ROOF CONSTRUCTION


STEP 5.

	TF3A	4		TL3	4		LG3	2
	J1	2		S3	12		S5	12




STEP 1.

Adjust the position of the door, mark on MTA1 and use the drill to drill through, then use S7 or S16 to connect.




STEP 2.


Adjust the door position until it opens and closes freely. use the holes on MTA1, drill new holes and fasten using S3.



STEP 3.


Install the latch in position as shown and fix with S16 or S7.








The shed is now free standing. It is critical at this stage, to ensure the shed is leveled. Also by measuring the diagonal distance, make sure the four side walls form a perfect square.

ANCHORING OF SHED




	C7	8
	S11	8






Fastening the anchor kit onto a concrete pad

1. Mark the spot of the anchor clamps on the ground
2. Use 10mm -0.39" concrete drill bit and drill holes 60mm-2.4" deep
3. Tap concrete fixing bolts into the hole, place anchor clamps, add washer and nut and fasten.



According to shed and quantity of the floor kits, equally divide the floor kits and install them.



	F08	14
	J1	7

